

## TROUBLESHOOTING - 3210 designed for jeans

Condition	Cause
<b>The machine is noisy and does not run smoothly.</b>	<ol style="list-style-type: none"> <li>1. Threads have been caught in the hook area.</li> <li>2. The feed dog is packed with lint.</li> </ol>
<b>The needle thread breaks.</b>	<ol style="list-style-type: none"> <li>1. The needle is not threaded properly.</li> <li>2. The needle thread tension is too tight.</li> <li>3. The needle is bent or blunt.</li> <li>4. The needle is not inserted correctly.</li> <li>5. The thread is either too heavy or too fine for the needle.</li> <li>6. The threads are not under the presser foot when sewing begins.</li> </ol>
<b>The bobbin thread breaks.</b>	<ol style="list-style-type: none"> <li>1. The bobbin thread is not threaded correctly in the bobbin holder.</li> <li>2. Lint has collected in the bobbin holder.</li> <li>3. The bobbin is damaged and does not turn smoothly.</li> </ol>
<b>The needle breaks.</b>	<ol style="list-style-type: none"> <li>1. The needle is not inserted correctly.</li> <li>2. The needle is bent or blunt.</li> <li>3. The needle clamp screw is loose.</li> <li>4. The needle thread tension is too tight.</li> <li>5. The needle is too fine for the fabric being sewn.</li> <li>6. The stitch selection knob has been turned while the needle was in the fabric.</li> </ol>
<b>Skipped stitches.</b>	<ol style="list-style-type: none"> <li>1. The needle is not inserted correctly.</li> <li>2. The needle is bent or blunt.</li> <li>3. The needle and/or the thread are not suitable for the fabric being sewn.</li> <li>4. A stretch needle is not being used for sewing stretch, very fine and synthetic fabrics.</li> <li>5. The needle thread is not threaded properly.</li> </ol>
<b>The seam puckers.</b>	<ol style="list-style-type: none"> <li>1. The needle thread tension is too tight.</li> <li>2. The machine is not threaded correctly.</li> <li>3. The needle is too large for the fabric being sewn.</li> <li>4. The stitch length is too long for the fabric.</li> <li>5. The foot pressure dial is not set correctly.</li> <li>6. Threads have been caught in the hook area.</li> </ol> <p><i>Place lightweight tearaway stabilizer under lightweight fabrics.</i></p>
<b>The stitches form loops underneath the fabric.</b>	<ol style="list-style-type: none"> <li>1. The needle thread tension is too loose.</li> <li>2. The needle is either too large or too small for the thread.</li> </ol>
<b>The fabric does not feed smoothly.</b>	<ol style="list-style-type: none"> <li>1. The feed dog is packed with lint.</li> <li>2. The pressure foot dial is not set correctly.</li> <li>3. The stitches are too short.</li> <li>4. The correct presser foot is not being used.</li> <li>5. The feed dog is lowered.</li> </ol>
<b>The machine does not work.</b>	<ol style="list-style-type: none"> <li>1. The machine is not plugged in.</li> <li>2. A thread is caught in the hook area.</li> <li>3. The bobbin winder spindle is in the winding position.</li> </ol>
<b>The buttonhole is not correct.</b>	<ol style="list-style-type: none"> <li>1. The stitch length is not suitable for the fabric being sewn.</li> <li>2. Interfacing is not being used with fabrics.</li> <li>3. Fine adjustment lever for buttonhole is not set properly.</li> </ol>